

*Construction Codes Requirements*  
**HIGH-PRESSURE BOILER SUPERVISION**

## BACKGROUND

- Section **AC §28-413** requires a high-pressure boiler be operated under the direct and continuing supervision and in the presence of a high-pressure boiler operating engineer
- Exceptions to the requirement of a licensed High-Pressure Boiler Operating Engineer are provided where certain conditions are met.



## HIGHLIGHTS

Clarification on when the requirement of a High-Pressure Boiler Engineer operating engineer license is required:

1. What is a stand-alone boiler for the purpose of applying AC §28-413.
2. How to apply exceptions to AC §28-413 in multiple stand-alone high-pressure boilers installations.

Read the full [Bulletin 2022-012](#) for more details on the requirements.

Send questions to [constructioncodes@buildings.nyc.gov](mailto:constructioncodes@buildings.nyc.gov).