

## NOTES:

- 1. TAP FOR THE FUSE CUT OUT MUST BE MADE ON THE LINE SIDE OF THE MAIN CIRCUIT BREAKER OR MAIN LUGS OF THE ELECTRICAL PANEL
- 2. A LISTED DEVICE MUST BE USED FOR TAPPING THE FEEDER CONDUCTORS.
- 3. ALL CONDUIT FOR NPLFA WIRING MUST BE IN RMC, IMC, OR MUST BE MI CABLE.
- 4. ALL FIRE ALARM DISTRIBUTION DEVICES AND PULL BOX COVERED MUST BE LABELED APPROPRIATELY AND BE RED IN FINISH.

## TYPICAL FIRE ALARM SUB-SYSTEM FUSE CUT OUT DETAIL

NOT TO SCALE