Using Your NFC Fob on a Vehicle without a Reservation





A vehicle is available for you to tap-n-go if the LED on the NFC reader is dark.

Start Rental





NFC reader. Do not release until the LED changes to a green/orange blinking cycle.

≈5 second hold to the

Doors should unlock in 15-30 seconds.

After driving off to start your trip





1 second tap to the NFC reader. LED should blink green and lock/unlock doors. Do not Long Tap, as it will end your rental.

≈5 second hold to the

After driving back to hub





Do not release until the LED changes to a green/orange blinking cycle and you hear the vehicle doors lock.

NFC reader.

