


Men kijan pou w pase aplikatè a nan pati prive ou pou pran yon echantiyon




1

Lave men ou.




2

Chèche yon pozisyon kote w ap konfòtab.




3

Kenbe aplikatè a nan mitan.




4

Separe gran lè v ki deyò yo epi fove aplikatè a nan kanal anndan an.




5

Vire aplikatè a senk (5) fwa nan kannal anndan ou epi retire li.



6

San ou pa mete aplikatè a atè, devise bouchon an.



7

Mete aplikatè a nan tib la epi kase pwent aplikatè a.



8

Revise bouchon an byen sere.



9

Lave men ou.

PA vide likid la nan tib la ni kase bouchon aliminyòm nan.

